

PERGOLA ASSEMBLY

- 1 Dig holes to a minimum depth of 2' 6". The centers of the holes can be determined by using the width of the arch
- 2 Assemble the top structure. Place the two pieces with 5 notches on the ground. Glue the 5 interlocking cross pieces in place. Screw the 4 slats to the cross pieces, spacing them evenly.
- 3 Using the arch width as a guide, bury the two inside posts. (the distance from ground level to the top of the inside posts varies with the gate height.)
- 4 Attach outside posts to inside posts with 30p nails provided. Caulk postcaps to inside posts.
- 5 Slide top structure over outside posts and screw through both faces into posts.
- 6 Attach gate if purchased.

